

NAUTIZ X9

QUICK START GUIDE



BSR idware GmbH

Jakob-Haringer-Str.3

A-5020 Salzburg


<https://www.bsr.at>

sales@bsr.at


handheld

① WHAT'S IN THE BOX


The pictures shown below may differ from the actual products.
To purchase additional or optional products, contact our
customer center.



Nautiz X9 Main Body



Standard Battery





USB Cable



Adaptor

② YOUR NAUTIZ X9




NOTE Do not remove transparent film unless you are using the pistol grip accessory

③ INSERT/REMOVE BATTERY

To insert the battery


1. Insert the battery.



The battery is secured by a red slider. Move the slider to the right to unlock the battery.




2. Slide the battery lock up.




To remove the battery

1. Slide the battery lock down.




2. Remove the battery.



④ INSERTING/EXTRACTING SIM/MICRO SD CARD


This is how you insert and remove the SIM/micro SD.



⑤ USING SCANNER


Using scanner

Press the [Side Scanner] button to start scanning.




Scanning Barcode

To scan a barcode, keep a distance of about 10 cm between the barcode and the barcode scanner window and scan the barcode at the correct angle.



⑥ POWERING ON/OFF

Press the [Power] button on the side of the terminal to turn it on/off.



⑦ BATTERY CHARGING

Use supplied power adapter to charge the Nautiz X9.

Please go to www.handheldgroup.com/knowledgebase to download more information.



BSR idware GmbH

Jakob-Haringer-Str.3

A-5020 Salzburg

<https://www.bsr.at>

sales@bsr.at

handheld

www.handheldgroup.com

Version 1.2